
Exercise



- Assume that one particle hits the detector represented by the capacitor of capacitance C.
- The arrival of the particle is represented by a current generator generating a current $I(t) = e\delta(t)$
- Losses in the capacitor are represented by a parallel resistor of resistance R.
- Voltage V across C is read out by an ideal amplifier that whose noise properties, represented by the generator $V_{n,}$ are those of the commercial amplifier discussed in the last lecture (assume white noise continues at higher frequencies)
- What is the minimum error on e if $R=100 \text{ k}\Omega$ and C 500 pF?





Example a low noise amplifier

Low-Noise Voltage Preamplifier

SR560 — DC to 1 MHz voltage preamplifier



