

# Experimental Methods Lecture 23

November 11<sup>th</sup>, 2020





• A linear two-port network is a system with multiple inputs and multiple outputs.




- This system is linear and time invariant. It constitutes a more accurate scheme for a measurement instrument, as it also includes the perturbation that a measurement device exerts on the physical system at its input.
- two-port networks need not to be passive, and may actively increase the physical energy of signals going through them. The most classical example are electrical active two-port devices, like voltage and/or current amplifiers.

AA 2020-2021 S. Vitale

### The voltage amplifier



- The device is constituted by two ports. In each port we find two signals:
  - The input current and voltage I<sub>i</sub> and V<sub>i</sub>
  - The output current and voltage V<sub>o</sub> and I<sub>o</sub>




• In the frequency domain, as the system is linear, we can write, (for instance)

$$\begin{vmatrix}
I_i = V_i/Z_i + G_{io}I_o \\
V_o = G_{oi}V_i + Z_oI_o
\end{vmatrix} \rightarrow \begin{pmatrix}
I_i \\
V_o
\end{pmatrix} = \begin{pmatrix}
1/Z_i & G_{io} \\
G_{oi} & Z_o
\end{pmatrix} \cdot \begin{pmatrix}
V_i \\
I_o
\end{pmatrix}$$

•  $Z_i$  is called input impedance,  $Z_o$  output impedance, and non diagonal coefficients are often called gains.

## The voltage amplifier






• Adding the new branches, these are now the circuit equations:

$$I_{i} = \frac{V_{i}}{Z_{i}} + G_{io}I_{o} \ V_{o} = G_{oi}V_{i} + Z_{o}I_{o} \ I_{i} = \frac{V_{s} - V_{i}}{Z_{s}} \ V_{o} = -Z_{l}I_{o}$$

- These can now be solved in the general case.
- We are however interested in the limiting case (ideal amplifier) in

which, 
$$Z_i \rightarrow \infty$$
 and  $Z_L \rightarrow \infty$ . Then




•  $V_i = V_s - Z_s I_i \rightarrow V_s$   $V_o = G_{oi} V_i - \frac{Z_o}{Z_i} V_o \rightarrow G_{oi} V_i = G_{oi} V_s$ 


#### Noise in two port systems: voltage amplifier



• Thus, in conclusion the ideal noisy amplifier can be represented as



• Or, with a different graphics, and the simpler symbol G for the gain,



- As the output voltage is  $V_o = G(V_s + V_n + I_n Z_s)$ noise can be expressed at input as  $V_n^{in} = V_n + I_n Z_s$
- Notice that  $I_n$  truly circulate within  $Z_s$ . Thus the amplifier perturbs the source. This perturbation is often called the amplifier *back-action*

## Noise in two port systems: voltage amplifier

- In summary the noise at input of an ideal, noisy amplifier is  $V_n^{in} = V_n + I_n Z_s$
- Now remember  $\text{ If } z(t) = \alpha x(t) + \beta y(t)$
- Then  $S_{z,z}(\omega) = \alpha^2 S_{x,x}(\omega) + \beta^2 S_{y,y}(\omega) + 2\alpha\beta \text{Re}\{S_{x,y}(\omega)\}$
- Then  $S_{V_n^{in},V_n^{in}}(\omega) = S_{V_n,V_n}(\omega) + |Z_s(\omega)|^2 S_{I_n,I_n} + 2 \text{Re} \{S_{V_n,Z_sI_n}(\omega)\}$
- Furthermore  $R_{V_n,Z_sI_n}(\tau) = \left( \int_0^\infty Z_s(t')I_n(t+\tau-t')V_n(t)dt' \right) =$

$$R_{V_{n},Z_{s}I_{n}}(\tau) = \left\langle \int_{0}^{\infty} Z_{s}(t')I_{n}(t+\tau-t')V_{n}(t)dt' \right\rangle =$$


$$= \int_{0}^{\infty} Z_{s}(t')\langle I_{n}(t+\tau-t')V_{n}(t)\rangle dt' = \int_{0}^{\infty} Z_{s}(t')R_{V_{n},I_{n}}(\tau-t')dt'$$

Then  $S_{V_n,Z_s,I_n}(\omega) = Z_s(\omega)S_{V_n,I_n}(\omega)$ 

And  $S_{V_n^{in},V_n^{in}}(\omega) = S_{V_n,V_n}(\omega) + |Z_s(\omega)|^2 S_{I_n,I_n} + 2\text{Re}\{Z_s(\omega)S_{V_n,I_n}(\omega)\}$ 

#### Critical noise parameters for a 2-port device

- Noise at input  $V_n^{in} = V_n + I_n Z_s$
- Before proceeding further let's give a few important definitions:
- 1. Noise energy or temperature  $E_n(\omega) = k_B T_n(\omega) = \sqrt{S_{V_n V_n}(\omega)} S_{I_n I_n}(\omega)$
- 2. Noise Resistance  $R_n(\omega) = \sqrt{S_{V_n V_n}(\omega)/S_{I_n I_n}(\omega)}$ 3. Noise cross-coherence  $\rho_{n}(\omega) = S_{V,I}(\omega) / \sqrt{S_{V,V}(\omega)S_{I,I}(\omega)}$
- 1. Voltage PSD:  $S_{V_n V_n}(\omega) = k_B T_n(\omega) R_n(\omega)$
- 2. Current PSD  $S_{I_n I_n}(\omega) = k_B T_n(\omega) / R_n(\omega)$
- 3. Voltage-current cross spectrum  $S_{V_n I_n}(\omega) = k_B T_n(\omega) \rho_n(\omega)$



Inverting these definitions

#### Noise in a voltage amplifier



From previous page

$$S_{V_{n}V_{n}}(\omega) = k_{B}T_{n}(\omega)R_{n}(\omega); S_{I_{n}I_{n}}(\omega) = \frac{k_{B}T_{n}(\omega)}{R_{n}(\omega)}; S_{V_{n}I_{n}}(\omega) = k_{B}T_{n}(\omega)\rho_{n}(\omega)$$

• Total PSD at input, is given by

$$S_{V_{n}^{\text{in}}V_{n}^{\text{in}}}(\omega) = S_{V_{n}V_{n}}(\omega) + \left|Z_{s}(\omega)\right|^{2} S_{I_{n}I_{n}}(\omega) + 2 \operatorname{Re}\left\{Z_{s}(\omega)S_{V_{n}I_{n}}(\omega)\right\}$$

becomes, by substituting the definition above:


$$S_{V_{n}^{in}V_{n}^{in}}(\omega) = k_{B}T_{n}(\omega) \left[ R_{n}(\omega) + \left| Z_{s}(\omega) \right|^{2} / R_{n}(\omega) + 2 Re \left\{ Z_{s}(\omega) \rho_{n}(\omega) \right\} \right]$$

Voltage noise depends on the impedance of the source and on that of noise

### Adjusting noise resistance



• Now we want to show that, at least to some approximation, the noise resistance can be adjusted without affecting the noise temperature. To do this, put an m-turns ideal transformer at the input of our amplifier:



You can calculate that :

$$\begin{split} V_{S} &= I_{i}(Z_{S} + sL_{p}) + m \ sL_{p}I_{n} = 0 \\ I_{i} &= \frac{V_{S} - m \ sL_{p}I_{n}}{Z_{S} + sL_{p}} \\ V_{i} &= s \ mL_{p} \frac{V_{S} - m \ sL_{p}I_{n}}{Z_{S} + sL_{p}} + s \ m^{2}L_{p}I_{n} + V_{n} \\ V_{i} &= \frac{s \ mL_{p}}{Z_{S} + sL_{p}} \Big( V_{S} - \big( m \ s \ L_{p} + Z_{S}m + m \ s \ L_{p} \big) I_{n} + \frac{V_{n}}{m} \frac{Z_{S} + sL_{p}}{sL_{p}} \Big) \end{split}$$

## Adjusting noise resistance



• From

$$I_i = \frac{V_S - m \, s L_p I_n}{Z_S + s L_p}$$

$$V_{i} = \frac{s \, m L_{p}}{Z_{s} + s L_{p}} \left( V_{s} - \left( m \, s \, L_{p} + Z_{s} m + m \, s \, L_{p} \right) I_{n} + \frac{V_{n}}{m} \frac{Z_{s} + s L_{p}}{s L_{p}} \right)$$


Finally

$$I_{i} = \frac{V_{s} - m \, sL_{p}I_{n}}{Z_{s} + sL_{p}} V_{i} = \frac{s \, mL_{p}}{Z_{s} + sL_{p}} \left( V_{s} + Z_{s}(-m \, I_{n}) + \frac{V_{n}}{m} \frac{Z_{s} + sL_{p}}{sL_{p}} \right)$$

• Now make  $|sL_p| \gg |Z_s|$ 

$$I_i = -mI_n$$
  $V_i = m\left(V_S + Z_S(-mI_n) + \frac{V_n}{m}\right)$ 


Then the situation looks like this:



### Adjusting noise resistance



• The equivalent noise at input consists of a current noise  $I_n' = I_n m$  and voltage noise  $V_n' = V_n / m$ .



• The new noise parameters are then

$$k_{B}T_{n}'(\omega) \equiv \sqrt{\frac{S_{V_{n}V_{n}}(\omega)}{m^{2}}} m^{2}S_{I_{n}I_{n}}(\omega) = k_{B}T_{n}(\omega)$$

$$R_{n}'(\omega) \equiv \sqrt{\frac{S_{V_{n}V_{n}}(\omega)}{m^{2}}} / S_{I_{n}I_{n}}(\omega) m^{2} = \frac{R_{n}(\omega)}{m^{2}}$$

AA 2020-2021

 $\rho_n(\omega) = \rho_n(\omega)$ 

## Minimizing noise by impedance matching



Total noise PSD at input, at a given frequency

$$S_{V_{n}^{\text{in}}V_{n}^{\text{in}}}(\omega) = k_{B}T_{n}(\omega) \left[ R_{n}(\omega) + \left| Z_{s}(\omega) \right|^{2} / R_{n}(\omega) + 2 \operatorname{Re} \left\{ Z_{s}(\omega) \rho_{n}(\omega) \right\} \right]$$

• Can be minimized by adjusting  $R_n$ 

$$\frac{\partial S_{V_n^{in}V_n^{in}}(\omega)}{\partial R_n(\omega)} = k_B T_n(\omega) \left[ 1 - \left| Z_s(\omega) \right|^2 / R_n^2(\omega) \right] = 0$$
• That gives  $R_n(\omega) = \left| Z_s(\omega) \right|$ 

When this condition is fulfilled the contribution of voltage noise and

of current noise become equal and the PSD becomes
$$S_{V_n^{\text{in}}V_n^{\text{in}}}(\omega) = 2k_B T_n(\omega) \left[ \left| Z_s(\omega) \right| + \text{Re} \left\{ Z_s(\omega) \rho_n(\omega) \right\} \right]$$

• Or, for uncorrelated generators


S<sub>VinVin</sub> (
$$\omega$$
) = 2k<sub>B</sub>T<sub>n</sub>( $\omega$ ) | Z<sub>s</sub>( $\omega$ )

Watch out! This is not Nyquist law, and  $T_n$  is not T

## Noise figure and matched source



- We want to discuss now another noise minimization that achieves a similar result, but in term of source impedance.
- If the source impedance has a real part, at thermal equilibrium it will be noisy, with a noise PSD given by Nyquist formula.



• Total noise at input will then have a PSD (we omit the frequency dependence in order to simplify the writing), given by:

$$S_{V_{n}^{in}V_{n}^{in}} = k_{B}T_{n} \left[ R_{n} + |Z_{s}|^{2} / R_{n} + 2 Re \{Z_{s}\rho_{n}\} \right] + 2k_{B}TRe \{Z_{s}\}$$

AA 2020-2021 S. Vitale 13

## Noise figure and matched source



From the PSD

$$S_{V_{n}^{in}V_{n}^{in}} = k_{B}T_{n} \left[ R_{n} + \left| Z_{s} \right|^{2} / R_{n} + 2 Re \left\{ Z_{s} \rho_{n} \right\} \right] + 2k_{B}TRe \left\{ Z_{s} \right\}$$

• We define the noise figure as the ratio, *measured in decibels*, between the total noise PSD and that of the thermal noise alone

$$F = 20 \text{Log}_{10} \left\{ \frac{k_{\text{B}} T_{\text{n}} \left[ R_{\text{n}} + \left| Z_{\text{s}} \right|^{2} / R_{\text{n}} + 2 \text{Re} \left\{ Z_{\text{s}} \rho_{\text{n}} \right\} \right] + 2 k_{\text{B}} T \text{Re} \left\{ Z_{\text{s}} \right\}}{2 k_{\text{B}} T \text{Re} \left\{ Z_{\text{s}} \right\}} \right\}$$
• That is 
$$F = 20 \text{Log}_{10} \left\{ 1 + \frac{T_{\text{n}}}{T} \left[ \frac{R_{\text{n}}}{2 \text{Re} \left\{ Z_{\text{s}} \right\}} + \frac{\left| Z_{\text{s}} \right|^{2}}{2 R_{\text{n}} \text{Re} \left\{ Z_{\text{s}} \right\}} + \frac{\text{Re} \left\{ Z_{\text{s}} \rho_{\text{n}} \right\}}{\text{Re} \left\{ Z_{\text{s}} \right\}} \right] \right\}$$


- For uncorrelated noise sources this figure has a minimum when
- Whose value is  $F_{\min} = 20 \text{Log}_{10} \left\{ 1 + \frac{T_n}{T} \right\}$

# A practical example: a popular low-noise instrument amplifier

- From the attached noise figure plot, let's derive noise temperature and noise resistence at 100 Hz, 1 kHz and 10 kHz
- Calculate also the voltage and current PSD
- Notice: one sided PSD are used here



#### SR560 Noise Figure



AA 2020-2021 S. Y




## An experimental example


APPLIED PHYSICS LETTERS 93, 172506 (2008)

## 10 $\hbar$ superconducting quantum interference device amplifier for acoustic gravitational wave detectors

P. Falferi, <sup>1,2,a)</sup> M. Bonaldi, <sup>1,2</sup> M. Cerdonio, <sup>3,4</sup> R. Mezzena, <sup>5,2</sup> G. A. Prodi, <sup>5,2</sup> A. Vinante, <sup>4</sup> and S. Vitale <sup>5,2</sup>


- Current noise excites the resonant circuit (9 kHz).
- The PSD peak gives a measurement of the current noise
- Outside the resonance range the noise is dominated by voltage noise






AA 2020-2021 S. Vitale 16

#### 27 h SQUID amplifier operating with high-Q resonant input load



# The meaning of noise energy. One example: charge detector

- A charge detector consisting of a lossy capacitor read out by a low noise amplifier. I<sub>th</sub> is the Nyquist current noise generator associated with R. We will assume V<sub>n</sub> and I<sub>n</sub> to be uncorrelated.
- The signal at input consists of a single charge e. That is, the signal consists of a current impulse  $I(t)=e\delta(t)$
- What is the minimum measurable value of e, given the amplifier noise temperature and resistance?




AA 2020-2021 S. Vitale 1



- As the signal is a current, let's work at input, i.e. for current
- Fourier transform of the (unit amplitude) signal  $I(\omega) = 1$
- Let's call  $I'_n = I_n + I_{th}$ .
- Total input due to noise is:  $V_{i,noise} = V_n + ZI'_n$
- As an equivalent current  $I_{n,e} = I'_n + \frac{V_n}{Z}$
- Total equivalent input noise PSD ( $I_n$  and  $V_n$  white and uncorrelated)

$$S_{I_{n,e}I_{n,e}}(\omega) = S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}(1 + \omega^{2}R^{2}C^{2})}{R^{2}}$$

$$S_{I_{n,e}I_{n,e}}(\omega) = S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}} + S_{V_{n}V_{n}}\omega^{2}C^{2}$$





• Furthermore, from


$$S_{I_{n,e}I_{n,e}}(\omega) = S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}} + S_{V_{n}V_{n}}\omega^{2}C^{2}$$

• We get

$$S_{I_{n,e}I_{n,e}}(\omega) = \left(S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}}\right) \left(1 + \frac{S_{V_{n}V_{n}}C^{2}}{S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}}}\omega^{2}\right)$$

or

$$S_{I_{ne}I_{ne}}(\omega) = S_{Io}(1 + \tau^2\omega^2)$$





• Thus, signal


$$I(\omega) = 1$$

Noise

$$S_{I_{n,e}I_{n,e}}(\omega) = S_{Io}(1 + \tau^2 \omega^2)$$

• Wiener filter error

$$\sigma_{e} = \left(\frac{1}{2\pi} \int_{-\infty}^{\infty} \frac{1}{S_{Io}(1+\omega^{2}\tau^{2})} d\omega\right)^{-1/2} = \frac{\sqrt{S_{Io}\tau}}{\sqrt{\frac{1}{2\pi} \int_{-\infty}^{\infty} \frac{1}{1+x^{2}} dx}}$$
$$= \sqrt{2S_{Io}\tau}$$





• Thus,

$$\sigma_e = \sqrt{2S_{Io}\tau}$$

And

$$S_{I_{n,e}I_{n,e}}(\omega) = \left(S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}}\right) \left(1 + \frac{S_{V_{n}V_{n}}C^{2}}{S_{I'_{n}I'_{n}} + \frac{S_{V_{n}V_{n}}}{R^{2}}}\omega^{2}\right)$$

• with

$$S_{I_{n,e}I_{n,e}}(\omega) = S_{Io}(1 + \tau^2 \omega^2)$$

• Then

$$\sigma_e = \sqrt{2\left(S_{I_n'I_n'} + \frac{S_{V_nV_n}}{R^2}\right)\sqrt{\frac{S_{V_nV_n}C^2}{S_{I_n'I_n'} + \frac{S_{V_nV_n}}{R^2}}}} = \sqrt{2C}\left(S_{V_nV_n}\left(S_{I_n'I_n'} + \frac{S_{V_nV_n}}{R^2}\right)\right)^{\frac{1}{4}}$$

- Now take the limit for  $R \to \infty$  (low dissipations)
- Then

$$\sigma_e \to \sqrt{2C\sqrt{S_{V_nV_n}S_{I_n'I_n'}}} = \sqrt{2\ Ck_BT_n'}$$



• In conclusion

$$\sigma_e = \sqrt{2 \ C k_B T_n'}$$

• Now suppose that a charge  $\sigma_e$  is deposited on the capacitor. This will get an energy

$$E = \frac{1}{2}C\sigma_e^2 = k_B T_n'$$


- This is the crucial result: the minimum detectable energy is the noise energy of the amplifier
- Notice that if  $T \to 0$   $T'_n \to T_n$  as the thermal noise becomes negligible



- We answer the question by using optimal filter theory. We are looking in the data for a signal of known shape  $\delta(t)$  and unknown signal amplitude e.
- Let's then calculate in the frequency domain the signal contribution to  $V_i$ . The Fourier transform of  $I(t)=\delta(t)$  is just  $I(\omega)=1$ . Then

$$V_{i}(\omega) = I(\omega)R(1/i\omega C)/(R + 1/i\omega C) = I(\omega)R/(1 + i\omega CR)$$

• Notice (to be used later)  $V_i(t) = (1/C)e^{-t/RC}\Theta(t)$ 



AA 2020-20




• Noise. Let's first calculate transfer functions from generators to  $V_i$ . As usual we do that by considering noise as standard signals. Then

$$V_{i} = \left(I_{th} + I_{n}\right)R\left(1/i\omega C\right) / \left(R + 1/i\omega C\right) + V_{n} = \left(I_{th} + I_{n}\right)R / \left(1 + i\omega CR\right) + V_{n}$$

• As  $I_{th}$  and  $I_n$  are uncorrelated, we can write the PSD as (we omit the frequency dependence of  $T_n$  and  $R_n$ )

$$S_{V_n^{\text{in}}V_n^{\text{in}}} = (2k_BT/R + k_BT_n/R_n)[R^2/(1+\omega^2C^2R^2)] + k_BT_nR_n$$



AA 2020-20

- From signal  $V_i(\omega) = R/(1+i\omega CR)$
- And PSD  $S_{V_n^{\text{in}}V_n^{\text{in}}} = (2k_BT/R + k_BT_n/R_n)[R^2/(1+\omega^2C^2R^2)] + k_BT_nR_n$
- We calculate the SNR as

- $SNR = \left[ R^{2} / \left( 1 + \omega^{2} C^{2} R^{2} \right) \right] / \left\{ \left( 2k_{B} T / R + k_{B} T_{n} / R_{n} \right) \left[ R^{2} / \left( 1 + \omega^{2} C^{2} R^{2} \right) \right] + k_{B} T_{n} R_{n} \right\}$
- That can be simplified to  $SNR = 1/\{2k_{B}T/R + k_{B}T_{n}/R_{n} + k_{B}T_{n}R_{n}(1 + \omega^{2}C^{2}R^{2})/R^{2}\}$ 
  - input noise current. At this same point the signal is just  $I(\omega)=1$
- The SNR can be put in a more simple form

SNR = 
$$\frac{1}{2k_{\rm B}T/R + k_{\rm B}T_{\rm n}/R_{\rm n} + k_{\rm B}T_{\rm n}R_{\rm n}/R^2 + (k_{\rm B}T_{\rm n}/R_{\rm n})\omega^2R_{\rm n}^2C^2} = \frac{1}{S_{\rm Io}(1 + \tau_{\rm e}^2\omega^2)}$$

- Where  $S_{Io} = (k_{B}T_{n}/R_{n})(1 + (R_{n}/R)^{2} + (2T/T_{n})(R_{n}/R)); \tau_{e} = R_{n}C/\sqrt{1 + (R_{n}/R)^{2} + (2T/T_{n})(R_{n}/R)}$

Notice the denominator is the PSD of the noise converted into an



• According to optimal filter theory, the error on the estimate of the charge e is given by  $\sigma_e = 1/\sqrt{(1/2\pi)\int_{-\infty}^{\infty} SNR(\omega)d\omega}$ 

• with 
$$\sigma_e = 1/\sqrt{(1/2\pi)} \int_{-\infty} SNR(\omega) d\omega$$
• with 
$$SNR = 1/\left[S_{Io}(1+\tau_e^2\omega^2)\right]$$

• To perform the calculation, we assume that both  $T_n$  and  $R_n$  are frequency independent then

$$\sigma_e = \sqrt{S_{Io}} / \sqrt{(1/2\pi) \int_{-\infty}^{\infty} (1 + \tau_e^2 \omega^2)^{-1} d\omega} = \sqrt{2S_{Io} \tau_e}$$

• Now restore the meaning of symbols:

$$S_{Io} = k_{B}T_{n}/R_{n} \left(1 + \left(R_{n}/R\right)^{2} + \left(2T/T_{n}\right)\left(R_{n}/R\right)\right); \tau_{e} = R_{n}C/\sqrt{1 + \left(R_{n}/R\right)^{2} + \left(2T/T_{n}\right)}\left(R_{n}/R\right)$$

- Then  $\sigma_e = \sqrt{2S_{Io}\tau_e} = \sqrt{2k_BT_nC} \times \sqrt{\sqrt{1+(R_n/R)^2+(2T/T_n)(R_n/R)}}$
- Best you can do is when the detector is cold enough and not too lossy  $(2T/T_n)(R_n/R) << 1$  and  $(R_n/R) << 1$
- Then  $\sigma_e = \sqrt{2k_B T_n C}$ AA 2020-2021
  S. Vitale




• In summary the minimum error on the estimate of the charge is

$$\sigma_e = \sqrt{2k_B T_n C}$$

• Now suppose that a charge equal to  $\sigma_e$  is deposited onto the capacitor. This acquires an electrostatic energy.

$$E = \frac{1}{2} \frac{e^2}{C} = \frac{1}{2} \frac{2k_B T_n C}{C} = k_B T_n = E_n$$

- Thus the "minimum detectable charge" (with 100% error) is that depositing an amount of energy equal to the noise energy of the amplifier.
- This result is valid in general not just for charge detection.



## Further on the example of charge detector

- Equivalent circuit for charge detector • V<sub>n</sub> and I<sub>n</sub> white and uncorrelated
- We can define an effective total current noise  $\tilde{I}_n = I_n + I_{th}$
- With PSD  $\tilde{S}_{I_n I_n} = \frac{2k_B T}{R} + \frac{k_B T_n}{R} \equiv k_B \tilde{T}_n / \tilde{R}_n$ and then simplify the circuit as  $\tilde{T}_{n} = \sqrt{\left(\frac{2T}{R} + \frac{T_{n}}{R}\right)} T_{n} R_{n} = T_{n} \sqrt{1 + 2\frac{R_{n}T}{RT}}$ R  $\tilde{R}_{n} = \sqrt{\frac{T_{n}R_{n}}{2T/R + T_{n}/R_{n}}} = \frac{R_{n}}{\sqrt{1 + 2(R T/RT)}}$ Vitale




## Total noise at input

Total equivalent current noise through Z

$$S_{I_{n}I_{n}} = \frac{2k_{B}T}{R} + \frac{k_{B}T_{n}}{R_{n}} + \frac{k_{B}T_{n}R_{n}}{\frac{R^{2}}{1 + \omega^{2}R^{2}C^{2}}} = \frac{2k_{B}T}{R} + \frac{k_{B}T_{n}}{R_{n}} + \frac{k_{B}T_{n}R_{n}}{R^{2}} + \frac{k_{B}T_{n}R_{n}}{R^{2}} \omega^{2}R^{2}C^{2} = S_{Io}(1 + \omega^{2}\tau_{e}^{2})$$

$$S_{Io} = \frac{2k_{B}T}{R} + \frac{k_{B}T_{n}}{R_{n}} + \frac{k_{B}T_{n}R_{n}}{R^{2}} \quad \tau_{e}^{2} = C^{2}R_{n}^{2} \frac{T_{n}/R_{n}}{\frac{2T}{R} + \frac{T_{n}R_{n}}{R^{2}}}$$

For  $R \to \infty$   $S_{Io} \to \frac{k_B T_n}{R_n}$   $\tau_e \to C R_n$ 







- A few additional notes on the exercise
- 2. The filter template.

According to theory, the best estimate is obtained by integrating the data multiplied by a template the Fourier transform of which is

$$h(\omega) = \sigma_e^2 V_i(\omega) / S_{V_n^{in} V_n^{in}}(\omega)$$

From previous calculations

$$h(\omega) = \sigma_e^2 \frac{V_{in}(\omega)}{S_{V_n^{in}V_n^{in}}(\omega)} = \sigma_e^2 \frac{\frac{R}{1+i\omega RC}}{\frac{S_{II}R^2}{1+\omega^2R^2C^2} + S_{VV}} = \frac{\sigma_e^2}{R} \frac{1-i\omega RC}{S_{II} + \frac{S_{VV}}{R^2}(1+\omega^2R^2C^2)}$$

That can be rewritten as

$$h(\omega) = \frac{\sigma_e^2}{R} \frac{1 - i\omega RC}{S_{Io} (1 + \omega^2 \tau_e^2)}$$